INSTRUCTION MANUAL

MODEL 143 20 MHz FUNCTION GENERATOR





INSTRUCTION MANUAL

MODEL 143 20 MHz FUNCTION GENERATOR

THIS DOCUMENT CONTAINS INFORMATION PROPRIETARY TO WAVETEK. THE INFORMATION IN THIS DOCUMENT IS NOT TOBE USED OR DUPLICATED IN ANY MANNER WITHOUT THE PRIOR APPROVAL IN WRITING OF WAVETEK.



9045 Balboa Ave., San Diego, Calif 92123 P O Box 651, San Diego, California 92112 Tel 714/279-2200 TWX 910 335 2007

WARRANTY

All Wavetek instruments are warranteed against defects in material and workmanship for a period of one year after date of manufacture. Wavetek agrees to repair or replace any assembly or component (except batteries) found to be defective, under normal use, during this period. Wavetek's obligation under this warranty is limited solely to repairing any such instrument which in Wavetek's sole opinion proves to be defective within the scope of the warranty when returned to the factory or to an authorized service center. Transportation to the factory or service center is to be prepaid by purchaser. Shipment should not be made without prior authorization by Wavetek.

This warranty does not apply to any products repaired or altered by persons not authorized by Wavetek, or not in accordance with instructions furnished by Wavetek. If the instrument is defective as a result of misuse, improper repair, or abnormal conditions or operations, repairs will be billed at cost.

Wavetek assumes no responsibility for its product being used in a hazardous or dangerous manner either alone or in conjunction with other equipment. High voltage used in some instruments may be dangerous if misused. Special disclaimers apply to these instruments. Wavetek assumes no liability for secondary charges or consequential damages and, in any event, Wavetek's liability for breach of warranty under any contract or otherwise, shall not exceed the purchase price of the specific instrument shipped and against which a claim is made.

Any recommendations made by Wavetek for use of its products are based upon tests believed to be reliable, but Wavetek makes no warranty of the results to be obtained. This warranty is in lieu of all other warranties, expressed or implied, and no representative or person is authorized to represent or assume for Wavetek any liability in connection with the sale of our products other than set forth herein.

CONTENTS

SECTION 1	GENERAL DESCRIPTION	
	1.1 THE MODEL 143	1-1 1-1
SECTION 2	INSTALLATION	
	2.1 MECHANICAL INSTALLATION	2-1 2-1 2-1
SECTION 3	OPERATION	
	3.1 CONTROLS AND CONNECTIONS 3.2 OPERATION 3.2.1 Signal Termination 3.2.2 Voltage Controlled Function Generator Operation 3.2.3 Waveforms	3-1 3-3 3-3 3-4
SECTION 4	CIRCUIT DESCRIPTION	
	4.1 BASIC WAVEFORM DEVELOPMENT 4.2 AMPLITUDE OFFSET AND ATTENUATION 4.3 TRIGGER AND GATE CONTROL	4-1 4-2 4-2
SECTION 5	CALIBRATION	
	5.1 FACTORY REPAIR 5.2 REQUIRED TEST EQUIPMENT 5.3 REMOVING GENERATOR COVERS 5.4 CALIBRATION	5-1 5-1 5-1
SECTION 6	TROUBLESHOOTING	
	6.1 FACTORY REPAIR 6.2 TROUBLESHOOTING CHARTS 6.3 TROUBLESHOOTING INDIVIDUAL COMPONENTS	6-1 6-1 6-1
SECTION 7	DADTE AND CCHEMATICS	

SAFETY

This instrument is wired for earth grounding via the facility power wiring. Do not bypass earth grounding with two wire extension cords, plug adapters, etc.

BEFORE PLUGGING IN the instrument, comply with installation instructions.

MAINTENANCE may require power on with the instrument covers removed. This should be done only by qualified personnel aware of the electrical hazards.

WARNING notes call attention to possible injury or death hazards in subsequent operations.

CAUTION notes call attention to possible equipment damage in subsequent operations.

SECTION GENERAL DESCRIPTION

1.1 THE MODEL 143

The Model 143 20 MHz Function Generator is a precision source of sine, triangle and square waveforms, negative and positive pulses and dc levels. All are front panel and external control variable from 0.0001 Hz to 20 MHz and can be modulated, swept or dc controlled over a 1000:1 range by an external voltage. Output can be continuous or the generator can be triggered or gated by an external voltage or front panel switch.

The waveform amplitude can be varied up to 30 volts peak-to-peak (open circuit) and attenuated up to 80 dB. Pulse amplitude can be varied from ±15 volts peak (open circuit). DC voltage or dc offset of signal is variable by front panel control and by external control between ±15 volts (open circuit). Waveform symmetry is variable from 19:1 to 1:19 for control of duty cycle and ramp rise/fall times. Triggered waveform start/stop point is adjustable for creation of special waveforms such as the haversine. A voltage representing generator frequency and a TTL level sync pulse at the frequency of the generator are auxiliary outputs.

1.2 SPECIFICATIONS

1.2.1 Versatility

Waveforms

Selectable sine \wedge , square \square , triangle \wedge , positive square \square , negative square \square , TTL sync pulse and dc. Symmetry of waveforms may be varied for sawtooth and variable duty cycle pulses.

Operational Modes

Continuous: Generator oscillates continuously at selected frequency.

Triggered: Generator is quiescent until triggered by an external signal or manual trigger, then generates one cycle at selected frequency.

Gated: As triggered mode, except generator oscillates for the duration of the gate signal.

Frequency Range

0.0001 Hz to 20 MHz in 10 overlapping ranges with 1% vernier control.

Function Output

 $^{\circ}$, $^{\circ}$, $^{\circ}$ selectable and variable to 30V p-p (15V p-p into 50 Ω). $^{\circ}$, $^{\circ}$, to 15 Vp (7.5 Vp into 50 Ω). All waveforms and dc can supply 150 mA peak current and may be attenuated to 60 dB in 20 dB steps with an additional 20 dB vernier.

DC Output and DC Offset

Selectable thru FUNCTION OUT output. Controlled by front panel control or by applying an external voltage. Adjustable between ± 15 Vdc $(\pm 7.5$ Vdc into $50\Omega)$ with signal peak plus offset limited to ± 15 Vdc $(\pm 7.5$ Vdc into $50\Omega)$. External offset sensitivity approximately -1 V/V with output into open circuit. DC offset and output waveform attenuated proportionately by the 60 dB output attenuator.

Sync Output

A TTL level pulse. Will drive 50Ω termination.

GCV - Generator Controlled Voltage

At GCV OUT connector, a 0 to +2V signal proportional to generator frequency. 600Ω source impedance.

VCG - Voltage Controlled Generator

Up to 1000:1 frequency change with external 0 to 2 volt signal to VCG IN connector. Upper and lower frequencies limited to maximum and minimum of selected range.

Slew rate: 2% of range per μ s.

Linearity:

 $\pm 0.2\%$ for 10 Hz to 100 kHz. $\pm 0.75\%$ for 0.001 Hz to 2 MHz. Input Impedance: 2 k Ω .

Trigger and Gate

Input Range: 1V p-p to ±10V. Impedance: 10 kΩ, 33 pF. Pulse Width: 25 ns minimum. Repetition Rate: 10 MHz maximum.

Adjustable Triggered Signal Start/Stop Point (sine and triangle only): Approximately -90° to +90° to 2 MHz.

Symmetry

Symmetry of all waveform outputs is continuously adjustable from 1:19 to 19:1. Varying symmetry provides variable duty cycle pulses, sawtooth ramps and distorted sine waves.

NOTE

When SYMMETRY control is used, indicated frequency is divided by approximately 10.

1.2.2 Frequency Precision

Dial Accuracy

 $\pm 3\%$ of full range from X .01 Hz to X 1 MHz. $\pm 5\%$ of full range on X 10 MHz.

Time Symmetry

Square wave variation less than: $\pm 1\%$ from 0.001 Hz to 200 kHz $\pm 0.5\%$ from 20 Hz to 20 kHz

1.2.3 Amplitude Precision

Amplitude Change With Frequency

Sine variation less than: 0.1 dB for 0.001 Hz to 200 kHz 0.5 dB for 200 kHz to 2 MHz 3.0 dB for 2 to 20 MHz

Step Attenuator Accuracy

0.3 dB per 20 dB step at 2 kHz.

1.2.4 Waveform Characteristics

Sine Distortion

<0.5% on X 100 Hz to X 10 kHz. <1.0% on X .01 to X 10 Hz and X 100 kHz. All harmonics 34 dB below fundamental on X 1 MHz. All harmonics 26 dB below fundamental on X 10 MHz.

Square Wave Rise/Fall Times

At FUNCTION OUT < 20 ns for 15V p-p output into 50 Ω load

1.2.5 General

Stability

Short Term: $\pm 0.05\%$ for 10 minutes. Long Term: $\pm 0.25\%$ for 24 hours.

Percentages apply to amplitude, frequency and dc offset.

Environmental

Specifications apply at 25°C ±5°C. Instrument will operate from 0°C to 50°C ambient temperatures.

Dimensions

28.6 cm (11 $\frac{1}{4}$ in.) wide; 13.3 cm (15 $\frac{1}{4}$ in.) high; 27.3 cm (10 $\frac{3}{4}$ in.) deep.

Weight

5 kg (11 lb) net; 6.6 kg (14½ lb) shipping.

Power

90 to $105V,\,108$ to $126V,\,198$ to 231V and 216 to 252V selectable; 48 to 400 Hz; less than 30 watts.

NOTE

All specifications apply from 10 to 100% of a selected frequency range, when FUNCTION OUT is at maximum and 50Ω terminated, with SYMMETRY control at OFF. Symmetry and vernier affect frequency calibration. Maximum possible asymmetry is a function of frequency setting.

SECTION 2

2.1 MECHANICAL INSTALLATION

After unpacking the instrument, visually inspect all external parts for possible damage to connectors, surface areas, etc. If damage is discovered, file a claim with the carrier who transported the unit. The shipping container and packing material should be saved in case reshipment is required.

2.2 ELECTRICAL INSTALLATION

2.2.1 Power Connection

WARNING

To preclude injury or death due to shock, the third wire earth ground must be continuous to the facility power outlet. Before connecting to the facility power outlet, examine extension cords, autotransformers, etc., between the instrument and the facility power outlet for a continuous earth ground path. The earth ground path can be identified at the plug on the instrument power cord; of the three terminals, the earth ground terminal is the nonmatching shape, usually cylindrical.

CAUTION

To prevent damage to the instrument, check for proper match of line and instrument voltage and proper fuse type and rating.

NOTE

Unless otherwise specified at the time of purchase, this instrument was shipped from the factory with the power transformer connected for operation on a 108 to 132 Vac line supply and with a 0.5 amp slow blow fuse.

Conversion to other input voltages requires a change in rear panel fuse-holder voltage card position and slow blow fuse according to the following table and procedure.

Card Position	Input Vac	Fuse
100	90 to 105	0.5 amp
120	108 to 126	0.5 amp
220	198 to 231	0.25 amp
240	216 to 252	0.25 amp

- Open fuse holder cover door and rotate fuse pull to left to remove the fuse.
- Select operating voltage by orienting the printed circuit board to position the desired voltage on the top left side. Push the board firmly into its module slot.
- Rotate the fuse-pull back into the normal position and insert the correct fuse into the fuse holder. Close the cover door.
- Connect the ac line cord to the mating connector at the rear of the unit and the power source.

2.2.2 Signal Connections

Use 3 foot RG58U 50Ω shielded cables equipped with female BNC connectors to distribute all input and output signals.

2.3 ELECTRICAL ACCEPTANCE CHECK

This checkout procedure is a general verification of generator operation. Should a malfunction be found, refer to the warranty in the front of this manual.

A two channel oscilloscope, four 3 foot 50Ω coax cables with female BNC connectors, a coax tee connector and a function generator are required for this procedure.

Preset the generator front panel controls as follows:

Control	Position
Dial	1.0
GENERATOR MODE	CONT
TRIGGER LEVEL	9 o'clock
TRIGGER START/STOP	. 0° CAL
ATTENUATION	
ATTENUATION VERNIER	
FUNCTION	Ъ
DC OFFSET	
SYMMETRY	
FREQUENCY MULT	
VERNIER	. Full cw

Set up the oscilloscope, Model 143 and external generator as shown in figure 2-1.




Figure 2-1. Initial Setup

Table 2-1. Acceptance Procedure

Step	Control	Position/Operation	Observe
1	POWER	ON	1 kHz square wave.
2	Diał	Rotate dial. Return to 1.0.	Rotation ccw increases frequency of square on one channel and dc level on other channel; cw decreases frequency and dc level.
3	FREQUENCY MULT	Rotate switch. Return to 1K.	Rotation cw increases frequency; ccw decreases frequency (dc level not affected).
4	VERNIER	Rotate ccw. Return to CAL.	Rotation ccw gives a small decrease in frequency.
5	ATTENUATION	Rotate ccw. Return to 0.	Rotation ccw reduces square wave amplitude.
6	ATTENUATION VERNIER	Rotate ccw.	Square wave amplitude decreases.
7	DC OFFSET	Rotate cw. Return to OFF.	Square wave is immediately offset below previous level; then waveform moves up to a positive level. OFF returns waveform to original position. (Clipping occurs at ±15V.)
8	Function Generator or Voltage Source	Vary input voltage.	Waveform dc level varies.

9	Function Generator or Voltage Source	Vary input voltage; then disconnect input.	Frequency increases with increased voltage, decreases with decreased voltage.
10	ATTENUATION VERNIER	Rotate cw.	
11	FUNCTION	Rotate to DC, ◇ , ◇ ,	Note dc level on scope. $ egthinspace \footnote{\coloredge} \foot$
12	SYMMETRY	Rotate cw, then to OFF.	Waveform changes from $^{\wedge}$ to $^{\wedge}$ to $^{\wedge}$ and frequency decreases, then to $^{\wedge}$ at original frequency.

Table 2-1. Acceptance Procedure (Continued)

Step	Control	Position/Operation	Observe					
13	GENERATOR MODE	GATE	A dc level.					
14	MANUAL TRIG	Press down.	A series of sine waves.					
	Set up a trigger source as shown in figure 2-2. Trigger on triangle waveform. Set trigger source at 100 Hz $$ $$							
15 TRIGGER LEVEL		Rotate knob. Set for several cycles.	Knob varies number of cycles gated.					
16	GENERATOR MODE	TRIG	One cycle per trigger cycle.					
17	TRIGGER START/STOP	Rotate knob, then to 0° CAL.	CW starts sine wave at $+90^{\circ}$; ccw starts sine wave at -90° . Fully cw gives continuous sine waves.					
	MODEL 143 FUNC OUT TRIG IN SYNC OUT TRIG OSCILLOSCOPE FUNCTION GENERATOR TRIG OUT TRIG OUT TRIG OUT TRIG OUT TRIG OUTPUT							

Figure 2-2. Second Setup

as a trigger or gate in the trigger and gate modes. The trigger level can be varied from fully cw, where a positive-going excursion thru approximately –10V is a trigger, to fully ccw, where a positive-going excursion thru approximately +10V level is a trigger.

(4) MANUAL TRIGGER Switch

Triggers or gates the output signal when GENER-ATOR MODE switch 3 is at TRIG or GATE. In trigger mode, one cycle is output when the switch is pressed. In gate mode, cycles are continuously output as long as the switch is held down.

NOTE Set TRIGGER LEVEL 3 fully ccw.

(5) TRIGGER START/STOP Control

Sets the start and stop point of the sine or triangle waveform appearing at (7). Usually used in the trigger mode and in combination with (10) to create desired waveforms. 0° CAL position ensures conventional waveforms symmetrical about 0 Vdc.

(6) ATTENUATION Control

Outer knob reduces output voltage level of all output at FUNCTION OUT with increasing steps of attenuation.

VERNIER Control

Inner knob is a 20 dB vernier which controls the output within the steps of the outer knob. DC and offset voltages are not affected by this control.

(7) FUNCTION OUT Connector

The main output of the generator. The output of the function selected.

8 SYNC OUT Connector

Furnishes a TTL pulse for each cycle or period of the generator. To be used for scope or similar synchronization.

(9) FUNCTION Switch

Selects one of six output signals: dc, waveforms or pulses.

(10) DC OFFSET Control

Offsets the waveform or dc level at \bigcirc from -15V to +15V (open circuit; ±7.5V into 50 Ω). An OFF position ensures no offset.

(11) SYMMETRY Control

Normal symmetrical output results when SYM-METRY is set to OFF; an asymmetrical, or unbalanced, waveform results when SYMMETRY is set between \[\] and \[\] \]. (Asymmetrical operation reduces generator frequency to approximately 1/10th the normal output.) Figure 3-2 shows the effect of SYMMETRY control on the waveforms.

NOTE

When SYMMETRY control is used, the output frequency is different from the dial indicated frequency. The maximum symmetry ratio obtainable also depends on the frequency dial setting.

ASYMMETRY] [] (ROTATE CCW)	SYMMETRY (NORM)	ASYMMETRY (ROTATE CW)
^ <i>\</i> \	^	$\wedge\wedge$
$\sim \sim \sim$	\sim	\sim
ᠬ-ᠯ᠋᠊ᠯ᠋		
ע דייייי	حـد.	

Figure 3-2. Effect of SYMMETRY Control

12 TRIG IN Connector

Accepts a 1V p-p to ±10V external signal to trigger the generator. (Up to ±50V will not damage circuitry.) Triggers on rising edge of input which crosses TRIGGER LEVEL 3 setting from negative to positive.

(13) VCG IN Connector

Accepts 0 to +2V ac or dc voltages to vary up to 1000:1 the frequency and period of the outputs.

The upper and lower limits are defined by the maximum and minimum dial 2 settings multiplied by 4 . VCG input will not drive the generator beyond the normal dial limits of a range.

(14) FREQUENCY MULT Switch

The outer knob selects one of ten frequency multipliers for the dial (2) setting.

VERNIER Control

A fine adjustment of the frequency dial **2** setting.

Not GCV OUT Connector (Rear Panel) Shown

This connector gives a 0 to +2V signal proportional to the frequency of the generator within any given range. The signal can be used as the X drive for X-Y recorders.

Not EXT DC OFFSET IN Connector (Rear Panel) Shown

Applied voltage offsets the selected waveform linearly. Offset is 1V for each -1V applied with output connected into an open circuit. Maximum input is $\pm 15V$. Offset is affected by the attenuator (6)

3.2 OPERATION

Perform the initial checkout in Section 2 for the feel of the instrument. Any questions concerning individual controls and connectors may be answered in paragraph 3.1.

3.2.1 Signal Termination

Proper signal termination, or loading, of the generator connectors is necessary for its specified operation. For example, the proper termination of the main output is shown in figure 3-3. Placing the 50Ω terminator, or 50Ω resistance,




Figure 3-3. Signal Termination

in parallel with a higher impedance matches the receiving instrument input impedance to the generator output impedance, thereby minimizing signal reflection or power loss on the line due to impedance mismatch.

3.2.2 Voltage Controlled Function Generator Operation

Operation as a voltage controlled function generator (VCG) is as for a manually controlled function generator, only the frequency within particular ranges is additionally controlled with de levels (±2V excursions) injected at the VCG IN connector. Set the frequency dial to a reference from which the frequency is to be voltage controlled.

- For frequency control with positive dc inputs at VCG IN, set the dial for a lower frequency limit.
- For frequency control with negative dc inputs at VCG IN, set the dial for an upper frequency limit.
- For modulation with an ac input at VCG IN, set the dial at the desired center frequency. Do not exceed the maximum dial range of the selected frequency range.

Figure 3-4 is a nomograph with examples of dial and voltage effects. Example 1 shows that with 0V VCG input, frequency is as determined by the main dial setting, 1.0 in this




Figure 3-4. VCG Voltage-to-Frequency Nomograph

example. Example 2 shows that with a positive VCG input, output frequency is increased. Example 3 shows that with a negative VCG input, output frequency is decreased. (Note that the Output Frequency Factor column value must be multiplied by a frequency range multiplier to give the actual output frequency.)

NOTE

The frequency vernier must be rotated fully ccw for 1000:1 range.


Nonlinear operation results when the VCG input voltage is excessive; that is, when the attempted generator frequency exceeds the range setting

(2 times the multiplier setting) or in the other direction, 1/1000th of the range setting.

The up to 1000:1 VCG sweep of the generator frequencies available in each range results from a 2V excursion at the VCG IN connector. With the frequency dial set to 2.0, excursions between -2V and 0V at VCG IN provide the up to 1000:1 frequency sweep. With the dial set to .002, excursions between 0V and +2V at VCG IN provide the up to 1000:1 sweep within the set frequency range.

3.2.3 Waveforms

See figure 3-5 for definition of controllable waveform characteristics.



NOTES

- 1. Period is controlled by the generator frequency setting.
- 2. In trigger mode, just one period is generated for each trigger pulse.
- 3. DC offset plus peak waveform voltage > | 7.5V | causes waveform clipping.

Figure 3-5. Waveform Characteristics

SECTION OPERATION

3.1 CONTROLS AND CONNECTIONS

The generator front panel controls and connectors are shown in figure 3-1 and keyed to the following descriptions.

1 POWER Switch

Turns generator on and off.

(2) Frequency Dial

Settings under the dial index mark multiplied by (14) determine the output signal frequency. The frequency can be varied by the vernier (14) and the VCG signal (13)

(3) GENERATOR MODE Switch

Selects one of the following three modes.

CONT — Continuous output at FUNCTION OUT, and SYNC OUT connectors.

TRIG — DC level output at both output connectors until the generator is triggered by MANUAL TRIG-GER switch or with a signal at the TRIG IN connector. When triggered, the generator output is one cycle of waveform or one pulse period followed by a dc level.

GATE — As for TRIG except the output is continuous for the duration of the trigger signal at TRIG IN. The last cycle or period started is completed.

TRIGGER LEVEL Control

Determines the level at which the input trigger signal at the TRIG IN connector (12) is accepted




Figure 3-1. Controls and Connectors




Figure 4-1. Overall Block Diagram

SECTION 4

4.1 BASIC WAVEFORM DEVELOPMENT

The heart of the generator (the bold path in figure 4-1) is a triangle and square wave generator. The triangle waves are developed by capacitor charging ramps that are alternately reversed in polarity. The polarity reversal is caused by a flipflop circuit, or hysteresis switch, that in turn produces the square waves. The flip-flop changes states upon detecting amplitude limits of the charging ramps through the triangle amplifier.

As shown in figure 4-1, the VCG dial buffer sums the currents from the frequency dial, frequency vernier and VCG in connector. The VCG dial buffer is an inverting amplifier whose output voltage is used to control a positive current source and a negative current source. For symmetrical output waveforms, the currents from the two current sources are equal and directly proportional to the voltage of the VCG dial buffer output. The diode gate, which is controlled by the hysteresis switch, is used to switch the positive or the negative current to the integrating capacitor selected by the frequency multiplier. If the positive current is switched into the integrating capacitor, the voltage across the capacitor will rise linearly to produce the fall transition.

The triangle amplifier is a unity gain amplifier whose output is fed to the hysteresis switch. The hysteresis switch has two voltage limit points (+1.25 aand -1.25V) at its input.

During the time the output voltage of the triangle amplifier is rising, the output voltage of the hysteresis switch is positive, but when the output voltage of the triangle reaches +1.25V, it triggers the hysteresis switch causing the output to switch negative. Once the control voltage into the diode gate becomes negative, it will switch the positive current out and switch the negative current in to the integrating capacitor, so that the voltage across the capacitor will reverse, starting a linear decrease of the waveform. When the decreasing voltage reaches -1.25V, the output of the hysteresis switch will switch back to positive, reversing the process. This action generates the triangle waveform as shown in figure 4-2. Since the output of the hysteresis switch is a square wave, the result is simultaneous generation of a square wave and a triangle wave at the same frequency.




Figure 4-2. Basic Generator and Timing Diagram

The output frequency is determined by the magnitude of the capacitor selected by the frequency multiplier and the magnitude of the positive and negative current sources. Since the current sources are linearly proportional to the control voltage of the VCG circuit, the output frequency will also be linearly proportional to the control voltage.

When the symmetry control is turned on, the current of the negative current source is decreased by 19 times, and the fall time of the triangle is 19 times longer than the rise time of the triangle, resulting in an unsymmetrical waveform and a division of the frequency by a factor of 10. Gradually increasing the current from the negative current source adecreasing the current from the positive current source causes the time for the triangle to complete one cycle to remain constant, while the symmetry of the output waveform is continuously varied.

The output of the hysteresis switch is fed to the sync amplifier and also the square wave shaper. The square wave shaper consists of a shaping circuit which limits the square wave output swing to ± 1.25 V. For positive pulse outputs, it limits the output voltage swing from -1.25 to 0V; and for negative pulse outputs, it limits the output swing from 0 to ± 1.25 V.

The triangle wave from the triangle amplifier is coupled through a buffer amplifier and made available to the function selector switch. The buffer amplifier provides a low impedance to drive the sine converter circuit. The sine converter, using the nonlinear characteristics of its diodes, converts the triangle wave into a sine wave.

The square wave from the sync amplifier, processed through a one-shot and the sync out buffer, is externally available at the sync out connector. The sync pulse, then, is a TTL level pulse output of the generator frequency.

4.2 AMPLITUDE OFFSET AND ATTENUATION

The selected waveform is inverted and amplified in the preamplifier. The preamplified waveform is sent to the output amplifier.

The output amplifier is an inverting amplifier with a current limiting output stage for short circuit protection. The dc offset control provides the offset to the selected waveforms center reference. The dc offset can be set by voltage at the external dc offset connector. The output amplifier establishes the generator 0 dB attenuation reference. An output attenuator decreases this reference amplitude in operator selected 20 dB steps. The attenuator consists of three voltage dividers. Attenuation between the steps is provided by the attenuation vernier.

4.3 TRIGGER AND GATE CONTROL

Generator operation is controlled by allowing or preventing the timing capacitor to charge. For figure 4-3 shows in detail this portion of the circuit. For continuous operation, the trigger amplifier maintains a positive level above the positive peak developed by the charging capacitors. This reverse biases (turns off) the start/stop diode, and the trigger amplifier does not interfere with continuous operation.


When the trigger amplifier outputs some level below the positive peak charging level, the diode is forward biased

(turned on) to sink the integrating current from the current source, preventing the capacitors from charging to the positive peak. This stops waveform generation and holds the triangle output at some dc level called the trigger baseline. The trigger baseline is the level where a triangle waveform cycle starts and where it stops. This baseline is directly applicable to the triangle waveform and thus affects the sine wave. The square wave levels, output via the hysteresis switch, are not affected by the triangle baseline levels.

The normal trigger baseline is zero volts, analogous to 0° phase of a sine or triangle waveform. The trigger start/stop control offsets the trigger amplifier output and can change the baseline for starting and stopping a sine or triangle waveform from its negative peak (-90°) to its positive peak $(+90^{\circ})$ range. At the extreme positive peak level setting, though, the diode is again reverse biased and generator operation goes continuous.

When charging level is being held, the positive current generator still varies its output with corresponding frequency control inputs. These varying currents must be sunk through the diode to keep the timing capacitors from varying their charge, and thus varying the trigger baseline. The baseline compensation circuit monitors the output from the positive current generator to control the trigger amplifier and thus control the necessary compensating current through the diode.

The trigger control logic determines that after a waveform starts, it always stops at a complete cycle and at the same phase at which it started. The trigger control logic latches the trigger amplifier for an enabling output from the time the cycle starts to when the negative peak of the last cycle is reached (just one cycle in the trigger mode). Upon reaching the negative peak, the timing capacitor continues charging positive again, but stops upon reaching the trigger baseline. A square wave from the hysteresis switch synchronizes the last negative peak time for unlatching the trigger amplifier for its trigger baseline output.






Figure 4-3. Trigger Circuit and Timing

SECTION 5

5.1 FACTORY REPAIR

Wavetek maintains a factory repair department for those customers not possessing the necessary personnel or test equipment to maintain the instrument. If an instrument is returned to the factory for calibration or repair, a detailed description of the specific problem should be attached to minimize turnaround time.

5.2 REQUIRED TEST EQUIPMENT

5.3 REMOVING GENERATOR COVERS

- Invert the instrument, remove the four screws in the cover.
- Turn the instrument upright, remove the top cover, and remove the four screws securing the bottom cover.
- Replace the top cover and turn the instrument upside down.

NOTE

Remove the bottom cover only when it is necessary to make adjustments or measurements.

5.4 CALIBRATION

After referring to the following preliminary data, perform calibration, as necessary, per table 5-1. If performing partial

calibration, check previous settings and adjustments for applicability. See figures 5-1 and 5-2 for calibration point location.

- 1. Unless otherwise noted, all measurements made at the 50Ω OUT connector should be terminated into a 50Ω (±0.1%) load.
- Verify operation in TRIG and GATE modes by connecting an external generator to the TRIG IN BNC and observing proper operation of TRIGGER LEVEL and TRIGGER START/STOP controls (paragraph 3.1).
- Verify SYNC OUT is an approximate 30 ns positive pulse into 50Ω and that GCV OUT is a voltage proportional to dial position with a 2V max (open circuit).
- Start the calibration by connecting the unit to an ac source and setting the front panel switches as follows:

Dial
FREQ MULT
FREQ VERNIER Full cw
GENERATOR MODE CONT
TRIGGER LEVEL Full ccw
TRIGGER START/STOP 0° CAL
SYMMETRY OFF
DC OFFSET OFF
FUNCTION
ATTENUATION 20 1 0
ATTENUATION VERNIER Full ccw
POWERON

 Allow the unit to warm up at least 30 minutes for final calibration. Keep the instrument covers on to maintain heat. Remove covers only to make adjustments or measurements.

Table 5-1. Calibration Chart

Step	Check	Tester	Cal Points	Control Settings	Adjust	Desired Results	Remarks
1	Power Supply	D∨M	C111			+15 ±0.05 Vdc	If voltage is incorrect, proceed to step 3.
2			C112			15 ±0.05 Vdc	If voltage is correct, proceed to step 9.

Steps 3 - 7 are on the trig/pulse board. Place the cover on the generator and turn it upright. Remove the top cover for access to the trig/pulse board.

3	Power Supply	DVM	TP1 (COM) TP2 (±15 Vdc)	R27	+15 ±0.02 Vdc	
4			ТРЗ		-15 ±0.05 Vdc	
5			ТР4		+24 ±1 Vdc	
6]		TP5		-24 ±1 Vdc	
7			TP6		+5 ±0.2 Vdc	
	 	 				

If steps 3 - 7 were performed, place the cover on, invert the generator and warm up the generator for ½ hour. Remove the uppermost cover for generator board access when required.

8	Cap Mult Balance	DVM (DCV)	TP5 (COM) TP1		R55	< 5 mV	
9	Power Ampl Balance		FUNC- TION OUT		R181	0 ±0.01 Vdc	Terminate with 50Ω load.
10	Preamp Balance			ATTENUATION VERNIER: full cw	R252	0 ±0.01 Vdc	
11	VCG Null	Scope		FUNCTION: T	R12	Minimum fre- quency shift	Observe one cycle at 50 \(\mu \)s/div. Alternately short and open VCG IN BNC while adjusting R12.
12	1000:1 Freq			FREQ VERNIER: full ccw	R13 BOD Freq Adj	< 1 cycle (< 200 Hz)	Scope on .5 ms/div.

Table 5-1. Calibration Chart (Continued)

Step	Check	Tester	Cal Points	Control Settings	Adjust	Desired Results	Remarks
13	1000:1 Sym- metry	Scope	FUNC- TION OUT		R16 BOD Sym	Symmetrical wave- form	NOTE: Steps 13 and 14 are interactive.
14	Main Sym- metry			FREQ VERNIER: full cw Dial: 2.0 FREQ MULT: 1K	R35 TOD Sym	Symmetrical wave- form	
15	Sine Distor- tion	Distortion Analyzer, Scope		FUNCTION: △	R120 Triangle Balance	Symmetrical residue	Connect FUNCTION OUT to distortion analyzer and distortion analyzer output to scope. Set scope to .1V/div. Sync scope to SYNC OUT BNC loaded into 50Ω.
16					R93, R107 Triangle Peaks	Minimum sine distortion	If either adjustment is going near a stop, re- center both pots and return to step 15.
17	Main Freq	Frequency Counter/ Timer		FUNCTION: 1	R4 TOD Freq Adj	2000 ±10 Hz	Remove SYNC OUT cable.
18	Cap Mult Freq	·		FREQ MULT: 10	R48	20 ±0.1 Hz	
19	X 10M Freq			FREQ MULT: 10M Dial: Vary	C40	Best frequency tracking over X 10M range	
20	X 1M Freq			FREQ MULT: 1M Dial: Vary	C34	Best frequency tracking over X 1M range	This adjustment must be made each time step 20 is done.
21	Trigger Baseline	Scope		FUNCTION: ^ GENERATOR MODE: TRIG Dial: Vary	R162	Minimum shift of baseline around 0 Vdc	




Figure 5-1. Generator Board




Figure 5-2. Trig/Pulse Board

SECTION **6** TROUBLESHOOTING

6.1 FACTORY REPAIR

Wavetek maintains a factory repair department for those customers not possessing the necessary personnel or test equipment to maintain the instrument. If an instrument is returned to the factory for calibration or repair, a detailed description of the specific problem should be attached to minimize turnaround time.

6.2 TROUBLESHOOTING CHARTS

Troubleshooting charts are given in figures 6-1 thru 6-9. The charts do not cover every possible trouble, but will be an aid in systematically isolating faulty components.

Figure 6-1. Initial Checks, Generator Board

Figure 6-2. Generator Loop Checks, Generator Board

Figure 6-3. VCG Checks, Generator Board

Figure 6-4. Generator Output Checks

Figure 6-5. Trigger and Gate Mode Checks, Trig/Pulse Board

Figure 6-6. Power Supply Checks, Trig/Pulse Board

Figure 6-7. Generator Input and Output Checks

6.3 TROUBLESHOOTING INDIVIDUAL COMPONENTS

6.3.1 Transistor

- A transistor is defective if more than one volt is measured across its base emitter junction in the forward direction.
- A transistor when used as a switch may have a few volts reverse bias voltage across base-emitter junction.
- If the collector and emitter voltages are the same, but the base emitter voltage is less than 500 mV forward voltage (or reversed bias), the transistor is defective.
- A transistor is defective if its base current is larger than 10% of its emitter current (calculate currents from voltage across the base and emitter series resistors).

5. In a transistor differential pair (common emitter stages), either their base voltages are the same in normal operating condition, or the one with less forward voltage across its base emitter junction should be off (no collector current); otherwise, one of the transistors is defective.

6.3.2 Diode

 A diode is defective if there is greater than one volt (typically 0.7 volt) forward voltage across it.

6.3.3 Operational Amplifier (e.g., 741, 1458)


- The "+" and "-" inputs of an operational amplifier will have less than 15 mV voltage difference when operating under normal conditions.
- When the output of the amplifier is connected to the "-" input (voltage follower connection), the output should be the same voltage as the "+" input voltage; otherwise, the operational amplifier is defective.


6.3.4 Capacitor

- Shorted capacitors have zero volts across their terminals.
- Opened capacitor can be located (but not always) by using a good capacitor connected in parallel with the capacitor under test and observing the resulting effect.

6.3.5 Digital TTL IC's (e.g. 7400 Series)

- The device is operating correctly if the output high state is > +2.4V and low state is < +0.5V.
- The input must show the same two levels as in step 1.
 If the levels are between +0.8V and +2.0V, the connection to the driving circuit output is open.






*SYMMETRY TO OFF, FREQ VERNIER TO CAL, DIAL TO 2.0, ALL OTHERS TO 12 O'CLOCK

Figure 6-2. Generator Loop Checks, Generator Board

^{**}A NEGATIVE VOLTAGE HERE STOPS GENERATOR FOR TRIGGERED OPERATION

^{***}USE SCOPE AND HIGH IMPEDANCE PROBE



*SYMMETRY TO OFF, FREQ VERNIER TO CAL, DIAL TO 2.0, ALL OTHERS TO 12 O'CLOCK
**USE SCOPE AND HIGH IMPEDANCE PROBE FOR THIS AND SUBSEQUENT VCG MEASUREMENTS

Figure 6-3. VCG Checks, Generator Board





Figure 6-4. Generator Output Checks, Generator Board



"SYMMETRY TO OFF, FREQ VERNIER TO CAL, DIAL TO 2.0, ALL OTHERS TO 12 O'CLOCK

Figure 6-5. Trigger and Gate Mode Checks, Trig/Pulse Board (Page 1 of 2)

^{**}RETURN TRIG LEVEL CCW TO OPERATE MANUAL TRIGGER





Figure 6-5. Trigger and Gate Mode Checks, Trig/Pulse Board (Page 2 of 2)






Figure 6-6. Power Supply Checks, Trig/Pulse Board (Page 2 of 2)




Figure 6-7. Generator Input and Output Checks (Page 1 of 2)

SECTION PARTS AND SCHEMATICS

7.1 DRAWINGS

The following assembly drawings (with parts lists) and schematics are in the arrangement shown below.


7.2 ORDERING PARTS


When ordering spare parts, please specify part number, circuit reference, board, serial number of unit and, if applicable, the function performed.


7.3 ADDENDA


Under Wavetek's product improvement program, the latest electronic designs and circuits are incorporated into each Wavetek instrument as quickly as development and testing permit. Because of the time needed to compose and print instruction manuals, it is not always possible to include the most recent changes in the initial printing. Whenever this occurs, addendum pages are prepared to summarize the changes made and are inserted immediately inside the rear cover. If no such pages exist, the manual is correct as printed.


Drawings	Drawing No.
CHASSIS	
Assembly Drawing Schematic Parts List	0102-00-0589 0004-00-0101 1101-00-0589
GENERATOR BOARD	
Parts Locater Drawing Assembly Drawing (Sheet 2 of 2 only) Schematic Parts List	0100-00-0556 0101-00-0584 0103-00-0556 1100-00-0584
TRIG/PULSE BOARD	
Parts Locater Drawing Assembly Drawing (Sheet 2 of 2 only) Schematic Parts List	0100-00-0565 0101-00-0585 0103-00-0565 1100-00-0585























														H	
THIS DOCUMENT CONTY MATION AND DESIGN WAVETEK AND MAY NOT REASON EXCEPT CALIE MAINTENANCE WITHOUT	AIMS PROPRIETARY IMPOR I RIGHTS BELONGING TO T SE REPRODUCED FOR ANY BRATION, OPERATION, AND WRITTEN AUTHORIZATION														
REFERENCE DESIGNATION	No PART DESCRIPTION	ORIG-MFGK-PARI-NO	MFGR	MAVELER NO.	MIXAGI	REFERENCE DEBIGNATON	PANT DESCRIPTION	OH1u-MFGH-PAHT-NG	MF GR	T NAVE IEN No.	Two control	MEFEMENCE DES: -NATUMS	FEHT VESUR, MT. UN	v to UniGrafianoranios	v – Wham — make to Ni.
			+		1				+	4789-00-0043	+				1
R39 R231 R259	RES.MF,1/88,1%,4.75k	AN550-4751F AN550-4990F	THE	4701-03-4751	1	1	RES, MF. 8ET, MAICHED CON315714799-00-0043 THHU10045					3m5	POM:5104-01-0010	5104-99-0029	ANTE 5104-99-0029
R117 R14 R152 R20 H2 R232 R26 R27 R3 R37		RN55D-4991F	THE	4701-03-4991	10	RS4	RES,MF,1/4M,[1,]M PART OF 4789-04-0843 GTY10[[470]-13-1004				1 1	3114	FROM 15184-01-0010	5.04-99-0030	371K 510E-44-0030
R157	RE3,MF,1/88,13,49.9K	HN550-49921	fee	4701-03-4994	1	RS&	RE8, MF., 6M, 12, LOM	HL-181	CADDO	4799-00-0003	1.	HOME	MIRL,MU,22GA	15U-BLACK	GAV11 0000-32-2000
R851 R921	HES, MF, 1/88, 12,54.9	KN550-54H9F	THE	4701-03-5499	2	CR16 CR3 CR33 CR4 CH	1	184581	M1CR0		,	1 NOME NOME	#1RE,#U,226A] 150-840mm	GAYTT -000-32-2001
R235	RE8,MF,1/8M,12,56,2	RNSSD-SeRZF	TRM	4701-03-5629	1	CR19 CR26 CR29 CH30 CR31 CH6 CR7 CR6 CR9	DIODE	F0-777	FAIR	4807-02-0777	' 1	HONE	AIRE,HU,286A	15u+DHANGE	GAVIT 4000-32-2003
R148T R243 R246 R21 R40 H44 R86 R91	RES.MF.1/88.12,576	RN55D-5760F RN55D-6040F	1 Km Tim	4701-03-5760	3		9100€	FD-6666	FALR	4807-02-006	10 1	NONE	#1HE,MU,22GA	150-161604	11 VAU 11 VAU
R215 H217 H234 H244 R260 H268 R275	HES,MF,1/8H,11,61.9	HM55D-6189F	THE	4701-03-6060	1,	CR1 CR10 CR11 CR14 CR15 CR17 CR16 CR20 CR21 CR22 CR24 CR28 CR35 CR34 CR36 CR36 CR37 CR46				1	1 1	NONE	186,MU,2264	ISU-GREEN	SAV11 6000-32-2005
				1	1			}				NONE	A :KE, MU, 22GA	15U-BLUE	PAALL 0000-25-5000
R264 R270 R46	RES,MF,1/88,12,681	HN55D-6810F RN55D-6981F	1Re	4701-03-6810	2	CRIS CRIS	D100E,M/PR,F0-777	5082-2811	HP NY IR	4898-00-0004	2	NONE	#1RE,MU,2264 *1RE,MU,2264	15U-V10LE1	GAVIT 6000-12-2087
R135 R167 R190 R60	RES,MF,1/88,12,750	RN550-8481F	INE	4701-03-6981	,		UTY1214807-02-0777			1	1.) NOME	18E, NU. 2264	15U-HH1TE/BLACK	GAV11 6000-32-2008
R70			1			CR36 CR39 CR40 CR41 CR42 CR43 CR44 CR45	010DE,8E1,8-FD-777 WTY1814807-02-0777	182-500-98	MVIK	4698-00-0010	1	MONE	mIRE, mu. 2264	15U-RHITE/BROWN	GAYTT 6000-32-2091
R153 R156 R136 H166 R164 R261 R266 R77 R70	HES, NF, 1/69, 12, 7.5K	HNS50-7501F	THR	4701-03-7561	•	042	TRANS	5H251 9A	FAIR	4901-02-5191	1.	HOHE	11RE,MU,226A	15U-MMITE/RED	6AVIT 0000-32-2092
R154	RES,MF,1/8#,11,76,8K	RN550+7682F	THE	4701-03-7682	١,	843	TRAMS	2N2905A	FAIR	4901-02-9051	1 1	NOME	118E, MU, 22GA	15U-BHITE/ORANGE	GAVT1 6090-32-2093
R125	RES,MF, L/88, 12,825	#N550-8250F		9701-03-8250	1	912 H36 850	TRANS	243563	FAIR	4901-03-5630	3	MONE	#IRE,HU,22GA	150-WHITE/TELLOW	BAVIT 6000-52-2094
WAVETEK	TITLE PCA,GENERATOR	ASSEMBLY NO 1100-00-0			REV D	WAVETEK	TITLE PCA, GENERATOR	ASSEMBLY 1100-00-	NO.		REV	WAVETEK	TITLE PCA, SEMERATOR	1100-00	
PARTS LIST	PERFORMICA	PAGE 1 7	204		1 "	PARTS LIST	PCA, GENERATOR	PAGE 1 9			"	PARTS LIST	PLA; DENERA UK	PAGE: 1	
REFERENCE DESIGNATUM	NS PART DESCRIPTION	ORIG-MFGH-PART-NU	HFGR	WAVETEK NO.	417/PI	REFERENCE DESIGNATUR	S PANT DESCRIPTION	ORIG-MFGR-PART-NO	MFGR	MAVETEN NO.	917/91	REFERENCE DESIGNATURA	PART DESCRIPTION	ORIG-MFGR-PART-NO	NFGR BAVETER NO.
REFERENCE DESIGNATUR	NS PART DESCRIPTION	ORIG-MFGH-PART-NU	MFGR	WAYETEK NO.	41T/P1	REFERENCE DESIGNATUR	S PANT DESCRIPTION	ORIG-MFGR-PART-NO	MFGR	MAVETEN NO.	917/91	REFERENCE DESIGNATURA	PART DESCRIPTION	ORIG-MFGR-PART-NO	NFGR MAVETER NO.
REFERENCE DESIGNATUM	MES, MF, 1/8N, 12, 8.25x	ORIG-MFGK-PART-NU KNSSD-8251F	MFGR THM	#AVETEX NO.	41T/P1	REFERENCE DESIGNATUR	S PANT DESCRIPTION TRANS	ORIG-MFGR-PART-NO	MFGR FAIR	#AVETEN NO.	Q17/P1	REPERENCE DESIGNATORS	FART DESCRIPTION	ORIG-MFGR-PART-NO	MFGR MAJETEN NO.
R238 R249 R58 R59			THN		417/P1 3	015 016 037 049 039 048	TRANS TRANS	2H3640 2H3866	FAIR HOT	4901-03-6660		HONE 1C3 IC4 IC5	mIRE,MU,ZZGA	· · · · · · · · · · · · · · · · · · ·	
R238 R249 R58 R59 R122 R228	MEB, MF, 1/8H, 12, 8, 25x RES, MF, 1/8H, 12, 82, 5 RES, MF, 1/8H, 12, 909	%%550-8251F R%550-8285F R%550-9090F	THM TRM TRM	4701+03-8251 4701-03-8259 4701-03-9090	41Y/P1 3 1	015 016 037 049	TRANS	243640	FAIR	4901-03-6400		NONE 1C3 IC4 IC5 035 Q48	nIRE, MU, 2264 1C IC	15U-MMITE/GREEN Ma-741 AD 812	GAVTT 6000-52-2095 PAIR 17000-07-4100 ANDEV .7000-08-1200
R238 R249 R58 R59 R122 R228 R271	MES, MF, 1/8m, 12,8,25x RES, MF, 1/8m, 12,92,5 RES, MF, 1/8m, 12,909 MES, MF, 1/8m, 12,90,9	NHSSD-8251F RHSSD-8285F RHSSD-9090F RHSSD-90N9F	THM TRM TRM	4701-03-8251 4701-03-8259 4701-03-9090 4701-03-9099	417/P1 3 1 2	015 016 037 049 039 048 013 021 022 027 028 029 031 040 06	TRANS TRANS	2H3640 2H3866	FAIR HOT	4901-03-6660	4 2 9	MONE 1C3 1C4 1C5 935 948 1C1 1C2 1C6	#IRE,MU,226# IC IC	15U-MM17E/GREEN MA-74; AD 812 MC1450F	FAIR
R236 R249 R58 R59 R122 R228 R271 R7	MES, MF, 1/8m, 13, 8, 25x RES, MF, 1/8m, 13, 92, 5 RES, MF, 1/8m, 13, 90, 9 RES, MF, 1/4m, 13, 90, 9 RES, MF, 1/4m, 13, 14	%NSSD-0251F RNSSD-0285F RNSSD-9090F RNSSD-90N9F NNSSD-90N9F	THN THN THN TRN	4701-03-8251 4701-03-8259 4701-03-9090 4701-03-9099 4701-13-1004	2 1 1	015 016 037 044 039 040 013 021 022 027 028 020 031 040 06 010 011 014 017 019 023 024 026 030	TRANS TRANS TRANS	2H3640 2H3666 2K3903	FAIR MOT FAIR	4901-03-0400 4901-03-8660	4 2 9	NONE 1C3 IC4 IC5 035 Q48 1C1 IC2 IC6 IC9	mIRE,MU,ZZGA IC IC IC IC	15U-HHITE/GREEN HA-741 AD 812 HC1850F CA-3089	CAVTT 6000-52-2095 PAIR 17000-07-4100 ANDEV 7000-08-1200 MOT 17000-14-500 RCA 17000-50-4400
R230 R289 R58 P59 R122 R228 R271 R7 R253	MEB, MF, 1/6M, 12, 8, 25x RE3, MF, 1/6M, 12, 92, 5 RE3, MF, 1/6M, 12, 90, 9 RE3, MF, 1/6M, 12, 90, 9 RE3, MF, 1/6M, 12, 11 MEB, MF, 1/4M, 12, 121	MNSSD-8251F RNSSD-8285F RNSSD-9090F RNSSD-90N9F NN60D-1008F RN60D-1210F	THM TRM TRM	4701-03-8251 4701-03-8259 4701-03-9090 4701-03-9099 4701-13-1004 4701-13-1210	2 1 1 1 1 1	015 016 037 049 039 048 013 021 022 027 028 029 031 040 06	TRANS TRANS TRANS	2N3640 2N3666 2N3903 2N3905	FAIR MOT FAIR	4901-03-9050	9	MONE 1C3 1C4 1C5 935 948 1C1 1C2 1C6	#IRE,MU,226# IC IC	15U-MM17E/GREEN MA-74; AD 812 MC1450F	FAIR
R236 R249 R58 R59 R122 R228 R271 R7	MES, MF, 1/8m, 13, 8, 25x RES, MF, 1/8m, 13, 92, 5 RES, MF, 1/8m, 13, 90, 9 RES, MF, 1/4m, 13, 90, 9 RES, MF, 1/4m, 13, 14	%NSSD-0251F RNSSD-0285F RNSSD-9090F RNSSD-90N9F NNSSD-90N9F	THN THN THN THN THN	4701-03-8251 4701-03-8259 4701-03-9090 4701-03-9099 4701-13-1004	3 1 2 1 1 1 1 2	015 Gle 037 GA9 039 GA4 013 G21 U22 927 U28 029 031 GA9 GA9 010 G11 G14 G17 U19 023 G24 G26 D30 G32 031 G14 G4 G46 G46 047 051	TRANS TRANS TRANS	2H3640 2H3666 2K3903	FAIR HOT FAIR FAIR	4901-03-0400 4901-03-8660	4 2 9 17	NONE 1C3 IC4 IC5 035 Q48 1C1 IC2 IC6 IC9	mIRE,MU,ZZGA IC IC IC IC	15U-HHITE/GREEN HA-741 AD 812 HC1850F CA-3089	CAVTT 6000-52-2095 PAIR 17000-07-4100 ANDEV 7000-08-1200 MOT 17000-14-500 RCA 17000-50-4400
R230 R240 R56 R59 R122 R228 R271 R7 R233 R229 R222 R270 R01	MEB.MF,1/0m,12,8,25 RES.MF,1/0m,12,02,5 RES.MF,1/0m,12,000 MED.MF,1/0m,12,100 RES.MF,1/4m,12,11 MEB.MF,1/4m,12,12 MEB.MF,1/4m,12,12 MEB.MF,1/4m,12,000 RES.MF,1/4m,12,000	NHSSD-8251F RHSSD-9090F RHSSD-9090F RHSSD-9090F RHSDD-1008F RHSDD-1200F RHSDD-1240F RHSDD-1240F RHSDD-4240F RHSDD-6983F	TMN TRR THN THN TRR TRR TRR TRR	4701-03-6251 4701-03-6259 4701-03-999 4701-03-999 4701-13-1994 4701-13-1210 4701-13-1240 4701-13-4999 4701-13-685	3 1 2 1 1 1 1 2 1 1 1 2 1 1	015 016 037 049 039 048 013 021 U22 027 U28 020 031 040 04 010 011 014 017 U19 023 024 026 030 032 033 034 04 04 041 046 047 091	TRANS TRAMS TRAMS TRAMS TRANS TRANS TRANS	2N3040 2N3003 2N3005	FAIR MOT FAIR FAIN	4901-03-8660 4901-03-9050 4901-03-9050	4 2 9 17	NONE 1C3 IC4 IC5 035 Q48 1C1 IC2 IC6 IC9	mIRE,MU,ZZGA IC IC IC IC	15U-HHITE/GREEN HA-741 AD 812 HC1850F CA-3089	CAVTT 6000-52-2095 PAIR 17000-07-4100 ANDEV 7000-08-1200 MOT 17000-14-500 RCA 17000-50-4400
R230 R269 R58 R59 R122 R226 R271 R7 R233 R229 R229 R279 R81 R81 R81 R81	MED, MF, 1/8n, 12,0,25 MED, MF, 1/8n, 12,02,5 MED, MF, 1/8n, 12,000 MED, MF, 1/8n, 12,00,0 MED, MF, 1/4n, 12,11 MED, MF, 1/4n, 12,121 MED, MF, 1/4n, 12,124 MED, MF, 1/4n, 12,000 MED, MF, 1/4n, 12,000 MED, MF, 1/4n, 12,000 MED, MF, 1/4n, 12,000 MED, MF, 1/4n, 12,75	NH550-8251F NH550-8285F NH550-9990F NH550-9980F NH550-9880F NH500-1240F NH600-1240F NH600-4980F NH600-4980F NH600-7580F	THM IFR THM THM THM TRM THM TRM THM	4701-03-8251 4701-03-8259 4701-03-9990 4701-03-9999 4701-13-1210 4701-13-1220 4701-13-1240 4701-13-4999 4701-13-4999 4701-13-47509	3 1 2 1 1 1 2 1 1 2 2 1 2 2 2 2 2 2 2 2	015 016 037 049 039 040 013 021 022 027 028 029 031 040 08 010 011 014 017 019 023 024 026 030 032 031 024 020 032 047 051 036 045	TRAMB (MFFF, 203505) (TY 2214001-03-5630	2M3640 2M3666 2M3903 2M3905 2M5160 2M5666	FAIR MOT FAIR FAIH MOT NBC	4901-03-0400 4901-03-050 4901-03-050 4901-05-1500 4901-05-050	4 2 9 17	NONE 1C3 IC4 IC5 035 Q48 1C1 IC2 IC6 IC9	mIRE,MU,ZZGA IC IC IC IC	15U-HHITE/GREEN HA-741 AD 812 HC1850F CA-3089	CAVTT 6000-52-2095 PAIR 17000-07-4100 ANDEV 7000-08-1200 MOT 17000-14-500 RCA 17000-50-4400
R230 R240 R56 R59 R122 R228 R271 R7 R233 R229 R222 R270 R01	MEO.MF.1/00,12.0.25 RES.MF.1/00,12.02.5 RES.MF.1/00,12.00.0 MEO.MF.1/00,12.00.0 RES.MF.1/00,12.12.1 MEO.MF.1/00,12.12.12 MEO.MF.1/00,12.00.0 RES.MF.1/00,12.00.0 RES.MF.1/00,12.00.0 RES.MF.1/00,12.00.0 RES.MF.1/00,12.00.0	NHSSD-8251F RHSSD-9090F RHSSD-9090F RHSSD-9090F RHSDD-1008F RHSDD-1200F RHSDD-1240F RHSDD-1240F RHSDD-4240F RHSDD-6983F	TMN TRR THN THN TRR TRR TRR TRR	4701-03-6251 4701-03-6259 4701-03-999 4701-03-999 4701-13-1994 4701-13-1210 4701-13-1240 4701-13-4999 4701-13-685	3 1 2 1 1 1 2 1 1 2 4 1 1	015 GLo 037 G40 039 Gae 015 G21 U22 G27 U28 020 031 040 GB 010 G11 G17 G17 023 024 G20 030 032 031 034 G 041 040 047 091 036 G65 01 05	TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB(TRAMB, MFFF, 201356) (TY1214701-03-630) TRAMB, SEL, 226462 (TY114701-03-640)	283840 283800 283903 283905 285100 285400 182-501-52	FAIR MOT FAIR MOT NOT NOC	4901-01-0400 8901-03-9040 4901-03-9030 4901-05-1600 8901-05-8660 4998-00-0004	4 2 9 17 2 2 1	NONE 1C3 IC4 IC5 035 Q48 1C1 IC2 IC6 IC9	mIRE,MU,ZZGA IC IC IC IC	15U-HHITE/GREEN HA-741 AD 812 HC1850F CA-3089	CAVTT 6000-52-2095 PAIR 17000-07-4100 ANDEV 7000-08-1200 MOT 17000-14-500 RCA 17000-50-4400
R230 R280 R58 R59 R122 R226 R271 R7 R213 R220 R220 R270 R01 R221 R270 R220 R220 R220 R221	MED, MF, 1/8m, 12,0,25 MED, MF, 1/8m, 12,002,5 MED, MF, 1/8m, 12,000 MED, MF, 1/4m, 12,10,00 MED, MF, 1/4m, 12,11 MED, MF, 1/4m, 12,121 MED, MF, 1/4m, 12,124 MED, MF, 1/4m, 12,000 MED, 1/4m, 12	NHSSD-8251F NHSSD-8285F NHSSD-9000F NHSSD-9000F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F	THM TRM THM TRM THM TRM TRM TRM TRM TRM TRM TRM	4701-03-8251 4701-03-8259 4701-03-9099 4701-13-1004 4701-13-1210 4701-13-1240 4701-13-4983 4701-13-4883 4701-13-4999	GTT/PT	015 GL0 037 G40 039 G40 011 021 U22 027 U28 027 031 040 08 010 011 01 017 U19 023 024 020 032 031 024 020 032 037 031 0 041 046 038 045 01 05 01 020	TRAMB (MFFF, 203505) (TY 2214001-03-5630	2H3840 2H3840 2H3903 2H3905 2H5100 2H5400 122-501-52	FAIR FAIR FAIR MOT NOC NOTK	4901-03-9660 4901-03-9650 4901-03-9050 4901-05-1600 4901-05-1600 4901-05-0600 4998-00-0004	4 2 9 17 2 2 1	NONE 1C3 IC4 IC5 035 Q48 1C1 IC2 IC6 IC9	mIRE,MU,ZZGA IC IC IC IC	15U-HHITE/GREEN HA-741 AD 812 HC1850F CA-3089	CAVTT 6000-52-2095 PAIR 17000-07-4100 ANDEV 7000-08-1200 MOT 17000-14-500 RCA 17000-50-4400
R230 R269 R58 R59 R122 R226 R271 R7 R233 R229 R229 R279 R81 R81 R81 R81	MED, MF, 1/8m, 12,0,25 MED, MF, 1/8m, 12,002,5 MED, MF, 1/8m, 12,000 MED, MF, 1/4m, 12,10,00 MED, MF, 1/4m, 12,11 MED, MF, 1/4m, 12,121 MED, MF, 1/4m, 12,124 MED, MF, 1/4m, 12,000 MED, 1/4m, 12	NHSSD-8251F NHSSD-8285F NHSSD-9000F NHSSD-9000F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F	THM TRM THM TRM THM TRM TRM TRM TRM TRM TRM TRM	4701-03-8251 4701-03-8259 4701-03-9099 4701-13-1004 4701-13-1210 4701-13-1240 4701-13-4983 4701-13-4883 4701-13-4999	1 2 1 2 1 2 4 1 1	015 GLe 037 G40 039 G46 011 G21 U22 G27 U28 G27 G31 G40 G6 010 G11 G17 G17 G33 G24 G26 G32 G47 G31 G4 G41 G46 G47 G31 G4 G41 G46 G47 G31 G47 G41 G46 G47 G31 G47 G41 G46 G47 G31 G47 G41 G46 G47 G31 G47 G41 G46	TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB, #FP, 22115-1 (1712)(401-03-60) TRAMB, \$81, 28562 (1711)(401-05-62) TRAMB, #FP, 225685 UTT 221401-05-620	2M3840 2M3840 2M3903 2M3905 2M3905 2M368 182-501-52 182-501-55 182-501-53	FAIR MUT FAIR MUT NBC NVTK	4901-03-9660 4901-03-9650 4901-03-9050 4901-05-1600 4901-05-1600 4901-05-0600 4998-00-0004	4 2 9 17 2 2 1 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	NONE 1C3 IC4 IC5 035 Q48 1C1 IC2 IC6 IC9	mIRE,MU,ZZGA IC IC IC IC	15U-HHITE/GREEN HA-741 AD 812 HC1850F CA-3089	CAVTT 6000-52-2095 PAIR 17000-07-4100 ANDEV 7000-08-1200 MOT 17000-14-500 RCA 17000-50-4400
R230 R240 R58 R59 R122 R226 R271 R7 R233 R220 R220 R222 R270 R07 R07 R220 R220 R220 R221	MED.MF.1/0m,12.0.25 RES.MF.1/0m,12.025 RES.MF.1/0m,12.000 MED.MF.1/0m,12.000 MED.MF.1/0m,12.100 MED.MF.1/0m,12.100 MED.MF.1/0m,12.100 MED.MF.1/0m,12.100 MED.MF.1/0m,12.100 MED.MF.1/0m,12.100 MED.MF.1/0m,12.100 MED.MF.1/0m,12.100	NHSSD-8251F NHSSD-8285F NHSSD-9000F NHSSD-9000F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F	THM TRM THM TRM THM TRM TRM TRM TRM TRM TRM TRM	4701-03-8251 4701-03-8259 4701-03-9099 4701-13-1004 4701-13-1210 4701-13-1240 4701-13-4983 4701-13-4883 4701-13-4999	3 1 2 1 1 1 1 2 1 1 2 1 1 2 1 1 1 2 1 1 2 1 1 2 1 1 2 1 1 2 1 1 1 2 1 1 1 2 1	015 GL0 037 G40 039 G40 039 G40 013 G21 U22 G27 U28 020 G31 G40 G30 010 G11 G17 G19 023 G24 G20 G30 G32 031 G34 G40 G41 047 G91 036 G45 01 G5 01 U20 02 G5 G7 04 G9 NOME	TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB_MFFF, 201500 GTY1214001-03-0400 TRAMB_MFFF, 201500 TRAMB_MFFFF, 201500 TRAMB_MFFFFF, 201500 TRAMB_MFFFFFF, 201500 TRAMB_MFFFFFFF, 201500 TRAMB_MFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF	2M3840 2M3840 2M3903 2M3905 2M5400 1824501-52 1824501-55 1824501-53	FAIR MUT FAIR FAIR MUT MUT NOC NOTE NOTE NOTE	4901-03-0000 4901-03-0000 4901-03-0000 4901-05-1000 4901-05-0000 4908-00-0000 5100-02-0015	4 2 9 17 2 2 1 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	NONE 1C3 IC4 IC5 035 Q48 1C1 IC2 IC6 IC9	mIRE,MU,ZZGA IC IC IC IC	15U-HHITE/GREEN HA-741 AD 812 HC1850F CA-3089	CAVTT 6000-52-2095 PAIR 17000-07-4100 ANDEV 7000-08-1200 MOT 17000-14-500 RCA 17000-50-4400
R230 R280 R58 R59 R122 R226 R271 R7 R213 R220 R220 R270 R01 R221 R270 R220 R220 R220 R221	MED, MF, 1/8m, 12,0,25 MED, MF, 1/8m, 12,002,5 MED, MF, 1/8m, 12,000 MED, MF, 1/4m, 12,10,00 MED, MF, 1/4m, 12,11 MED, MF, 1/4m, 12,121 MED, MF, 1/4m, 12,124 MED, MF, 1/4m, 12,000 MED, 1/4m, 12	NHSSD-8251F NHSSD-8285F NHSSD-9000F NHSSD-9000F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F	THM TRM THM TRM THM TRM TRM TRM TRM TRM TRM TRM	4701-03-8251 4701-03-8259 4701-03-9099 4701-13-1004 4701-13-1210 4701-13-1240 4701-13-4983 4701-13-4883 4701-13-4999	GTY/P1 3 1 2 1 1 1 2 1 1 1 2 1 1 1 1 2 1 1 1 1	015 GLe 037 G49 039 G46 011 G21 UZZ G27 UZB 047 G31 G46 G4 010 G11 G17 U19 033 G16 G4 G4 047 G31 035 G15 G4 047 G31 036 G4 047 G31 036 G4 047 G31 036 G4 047 G31 048 G4 049 G4 04	TRANS	2H3640 2H3600 2H3903 2H3905 2H5600 2H5600 102-501-52 102-501-53 102-601-53	FAIR MUT FAIR FAIR MUT HUT NBC NVTK NVTK TVTK TVTK C18	4901-03-0400 4901-03-0500 4901-03-9030 4901-03-1000 4901-03-0800 4908-00-0000 4908-00-0000 5104-07-0000 5104-07-0000	2 2 1 3 1 1 1 1 1 3 5	NONE 1C3 IC4 IC5 035 Q48 1C1 IC2 IC6 IC9	mIRE,MU,ZZGA IC IC IC IC	15U-HHITE/GREEN HA-741 AD 812 HC1850F CA-3089	CAVTT 6000-52-2095 PAIR 17000-07-4100 ANDEV 7000-08-1200 MOT 17000-14-500 RCA 17000-50-4400
R230 R240 R58 R59 R122 R228 R271 R7 R223 R224 R225 R270 R67 R225 R270 R67 R226 R225 R220 R22/	MED, MF, 1/8#, 12,0,25 RES, MF, 1/8#, 12,00 MED, MF, 1/8#, 12,00 MED, MF, 1/8#, 12,10 MED, MF, 1/4#, 12,00 MED, MF, 1/4#, 12,10 MED, MF, 1/4#, 12,10	NHSSD-8251F NHSSD-8285F NHSSD-9000F NHSSD-9000F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F NHSSD-1200F	THM IPR IPR THM TRM TRM TRM TRM TRM TRM TRM TRM TRM TR	4701-03-8251 4701-03-8259 4701-03-9099 4701-13-1004 4701-13-1210 4701-13-1240 4701-13-4983 4701-13-4883 4701-13-4999	1 1 2 1 2 1 2 4 1 1 REV D	015 GL6 037 G49 039 G46 011 021 U22 027 U28 027 031 040 D6 010 011 014 017 U19 033 024 024 030 032 037 031 041 041 049 038 045 01 05 01 05 010 U20 02 03 07 08 00 NONE NONE NONE NONE SN1	TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB_MFFF, 201500 GTY1214001-03-0400 TRAMB_MFFF, 201500 TRAMB_MFFFF, 201500 TRAMB_MFFFFF, 201500 TRAMB_MFFFFFF, 201500 TRAMB_MFFFFFFF, 201500 TRAMB_MFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF	2H3840 2H3866 2H3903 2H3905 2H5160 2H566 102-501-52 102-501-53 102-60 2H1-53-001 2H1-53-001	FAIR HOT FAIR HOT NOC NOTE NOTE NOTE CIS CIS WITE	4901-03-0400 4901-03-0500 4901-03-9030 4901-03-1000 4901-03-0800 4908-00-0000 4908-00-0000 5104-07-0000 5104-07-0000	2 2 1 3 1 1 1 1 1 3 5	NONE 163 164 165 035 048 161 162 166 169 167 168 167 1	#182,MU, 2264 1C 1C 1C 1C	150-PHITE/GREEN MA-701 AD 812 MC1850- CA-3009 CA-3008	CAVIT 1000-32-209 *AIR 17000-07-810 *ANDEX 7000-08-1200 MCT 17000-15-800 MCA 17000-51-800
R230 R240 R58 R59 R122 R224 R271 R7 R233 R220 R222 R270 R22 R270 R224 R225 R220 R224 R225 R220 R227	MES, MF, 1/8m, 12,0,25 RES, MF, 1/8m, 12,02,5 RES, MF, 1/8m, 12,000 MES, MF, 1/8m, 12,100 MES, MF, 1/8m, 12,101 MES, MF, 1/8m, 12,121 MES, MF, 1/8m, 12,122 MES, MF, 1/8m, 12,123 MES, MF, 1/8m, 12,124 MES, MF, 1/8m, 12,124 MES, MF, 1/8m, 12,125 MES, MF, 1/8m, 12,105 MES, MF, 1/8m, 12,106 MES, MF, 1/8m, 12,10	MMSSD-8251F MMSSD-8285F MMSSD-9040F MMSSD-9040F MMSDD-1240F MMSDD-1240F MMSDD-1240F MMSDD-1240F MMSDD-983F MMS	THM IPR IPR THM TRM TRM TRM TRM TRM TRM TRM TRM TRM TR	4701-03-8251 4701-03-8259 4701-03-9099 4701-13-1004 4701-13-1210 4701-13-1240 4701-13-4983 4701-13-4883 4701-13-4999	3 1 2 1 1 1 2 1 2 4 1 1	015 GLe 037 GAP 019 GAP 011 021 U22 027 U28 020 031 041 041 041 041 031 031 042 031 042 033 034 044 041 040 047 031 038 045 01 05 01 02 02 03 07 06 0P NOME NOME	TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB,WPP, 201503 TRAMB,041, 201601000000000000000000000000000000000	2M3840 2M3840 2M3903 2M3905 2M3905 2M3905 2M3905 142-501-52 142-501-55 142-602 211-33-001 211-33-001 215-33-001-01-22 5104-94-022	FAIR HOT FAIR HOT NSC NVTK NVTK C18 C18 C18	4901-03-0400 4901-03-0500 4901-03-7050 4901-05-1000 4901-05-2840 4908-00-0004 4908-00-0004 5104-07-0005 5104-07-0005	17 2 2 2 1 1 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1	NONE 1C3 1C4 1C5 035 048 1C1 1C2 1C6 1C4 1C7 1C6 1C7 1C6	# 15E.MU.2268 1C 1C 1C 1C	150-mHTL/GREEN MA-721 AD 812 MC1856* CA-3000 CA31-008	GAVIT LeCOO-32-200 FAIR 7000-07-410 ANDER 7000-08-120 MOT 17000-18-300 MCA 17000-31-400 ANDER TOO TO
R230 R249 R58 R59 R122 R220 R271 R7 R223 R223 R229 R222 R279 R81 R223 R266 R224 R225 R226 R227 R52	MES, MF, 1/8m, 12,0,25 RES, MF, 1/8m, 12,02,5 RES, MF, 1/8m, 12,000 MES, MF, 1/8m, 12,100 MES, MF, 1/8m, 12,101 MES, MF, 1/8m, 12,121 MES, MF, 1/8m, 12,122 MES, MF, 1/8m, 12,123 MES, MF, 1/8m, 12,124 MES, MF, 1/8m, 12,124 MES, MF, 1/8m, 12,125 MES, MF, 1/8m, 12,105 MES, MF, 1/8m, 12,106 MES, MF, 1/8m, 12,10	NH550-8281F NH550-8287F NH550-9000F NH550-9000F NH550-1000F NH600-1240F NH600-1240F NH600-1240F NH600-1240F NH600-1240F NH600-4033 NH600-4033 NH600-4033 ASSEMBLY M 1100-00-0	THM IPR IPR THM TRM TRM TRM TRM TRM TRM TRM TRM TRM TR	4701-03-8251 4701-03-8259 4701-03-9099 4701-13-1004 4701-13-1210 4701-13-1240 4701-13-4983 4701-13-4883 4701-13-4999	3 1 2 1 1 1 2 1 2 4 1 1	015 GL6 037 G49 039 G46 011 021 U22 027 U28 027 031 040 D6 010 011 014 017 U19 033 024 024 030 032 037 031 041 041 049 038 045 01 05 01 05 010 U20 02 03 07 08 00 NONE NONE NONE NONE SN1	TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB,WPP, 201503 TRAMB,041, 201601000000000000000000000000000000000	2H3640 2H3606 2H3903 2h3905 2h5160 2H5606 182-561-55 182-501-55 182-501-53 167-600 211-33-001 215-33-001-01-22 ARREMANLY 1107-00	FAIR HOT FAIR HOT NSC NVTK NVTK C18 C18 C18	4901-03-0400 4901-03-0500 4901-03-7050 4901-05-1000 4901-05-2840 4908-00-0004 4908-00-0004 5104-07-0005 5104-07-0005	17 2 2 2 1 1 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1	NONE 163 164 165 035 048 161 162 166 169 167 168 167 1	alse, mu, 2264 16 16 17 17 18 18 19 19 19 19 19 19 19 19 19 19 19 19 19	150-mHTL/GREEN MA-721 AD 812 MC18507 CA-3040 CA31408	CAVIT 0000-33-200 FAIR 7000-07-010 ANDLY 7000-08-120 MOT 17000-16-120 RCA 17000-31-000 ATT
R230 R240 R58 R59 R122 R228 R271 R7 R223 R223 R224 R224 R270 R67 R224 R225 R226 R227 R52	MES, MF, 1/8m, 12,0,25 RES, MF, 1/8m, 12,02,5 RES, MF, 1/8m, 12,000 MES, MF, 1/8m, 12,100 MES, MF, 1/8m, 12,101 MES, MF, 1/8m, 12,121 MES, MF, 1/8m, 12,122 MES, MF, 1/8m, 12,123 MES, MF, 1/8m, 12,124 MES, MF, 1/8m, 12,124 MES, MF, 1/8m, 12,125 MES, MF, 1/8m, 12,105 MES, MF, 1/8m, 12,106 MES, MF, 1/8m, 12,10	NH550-8281F NH550-8287F NH550-9000F NH550-9000F NH550-1000F NH600-1240F NH600-1240F NH600-1240F NH600-1240F NH600-1240F NH600-4033 NH600-4033 NH600-4033 ASSEMBLY M 1100-00-0	THM IPR IPR THM TRM TRM TRM TRM TRM TRM TRM TRM TRM TR	4701-03-8251 4701-03-8259 4701-03-9099 4701-13-1004 4701-13-1210 4701-13-1240 4701-13-4983 4701-13-4883 4701-13-4999	3 1 2 1 1 1 2 1 2 4 1 1	015 GL6 037 G49 039 G46 011 021 U22 027 U28 027 031 040 D6 010 011 014 017 U19 033 024 024 030 032 037 031 041 041 049 038 045 01 05 01 05 010 U20 02 03 07 08 00 NONE NONE NONE NONE SN1	TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB,WPP, 201503 TRAMB,041, 201601000000000000000000000000000000000	2H3640 2H3606 2H3903 2h3905 2h5160 2H5606 182-561-55 182-501-55 182-501-53 167-600 211-33-001 215-33-001-01-22 ARREMANLY 1107-00	FAIR HOT FAIR HOT NSC NVTK NVTK C18 C18 C18	4901-03-0400 4901-03-0500 4901-03-7050 4901-05-1000 4901-05-2840 4908-00-0004 4908-00-0004 5104-07-0005 5104-07-0005	17 2 2 2 1 1 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1	NONE 163 164 165 035 048 161 162 166 169 167 168 167 1	#182,MU, 2264 1C 1C 1C 1C	150-PHTE/GREEN MA-701 AD 812 AC1850F CA-3049 CA31008 ASSEMBL 1100-01 PASC1 TOTAL	CAVIT G000-52-200
R230 R240 R58 R59 R122 R228 R271 R7 R223 R224 R225 R270 R67 R225 R270 R67 R226 R225 R220 R22/	MES, MF, 1/8m, 12,0,25 RES, MF, 1/8m, 12,02,5 RES, MF, 1/8m, 12,000 MES, MF, 1/8m, 12,100 MES, MF, 1/8m, 12,101 MES, MF, 1/8m, 12,121 MES, MF, 1/8m, 12,122 MES, MF, 1/8m, 12,123 MES, MF, 1/8m, 12,124 MES, MF, 1/8m, 12,124 MES, MF, 1/8m, 12,125 MES, MF, 1/8m, 12,105 MES, MF, 1/8m, 12,106 MES, MF, 1/8m, 12,10	NH550-8281F NH550-8287F NH550-9000F NH550-9000F NH550-1000F NH600-1240F NH600-1240F NH600-1240F NH600-1240F NH600-1240F NH600-4033 NH600-4033 NH600-4033 ASSEMBLY M 1100-00-0	THM IPR IPR THM TRM TRM TRM TRM TRM TRM TRM TRM TRM TR	4701-03-8251 4701-03-8259 4701-03-9099 4701-13-1004 4701-13-1210 4701-13-1240 4701-13-4983 4701-13-4883 4701-13-4999	3 1 2 1 1 1 2 1 2 4 1 1	015 GL6 037 G49 039 G46 011 021 U22 027 U28 027 031 040 D6 010 011 014 017 U19 033 024 024 030 032 037 031 041 041 049 038 045 01 05 01 05 010 U20 02 03 07 08 00 NONE NONE NONE NONE SN1	TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB,WPP, 201503 TRAMB,041, 201601000000000000000000000000000000000	2H3640 2H3606 2H3903 2h3905 2h5160 2H5606 182-561-55 182-501-55 182-501-53 167-600 211-33-001 215-33-001-01-22 ARREMANLY 1107-00	FAIR HOT FAIR HOT NSC NVTK NVTK C18 C18 C18	4901-03-0400 4901-03-0500 4901-03-7050 4901-05-1000 4901-05-2840 4908-00-0004 4908-00-0004 5104-07-0005 5104-07-0005	17 2 2 2 1 1 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1	NONE 163 164 165 035 048 161 162 166 169 167 168 167 1	TILL THILL PERSONNELL REMOVE ALL BLANES AND STAAL BLANES AND STAAL BLANES AND STAAL BLANES	150-PHTE/GREEN MA-701 AD 912 MC1450- CA-3009 CA-3009 AREAMAN 1100-00 PAGE1 THISTORY THISTOR	GAVIT 10000-52-2098 FAIR 17000-07-0106 ANDEL 7000-08-1201 MOT 17000-15-200 MCA 17000-51-200 MCA 17000-51-200 MCA 17000-51-200 MCA 17000-51-200 MCA 17000-51-200 MCA
R236 R269 R58 R59 R122 R228 R271 R7 R233 R229 R222 R279 R67 R222 R226 R226 R227 R52 R53	MED, MF, 1/6m, 12,6,25% RES, MF, 1/6m, 13,02,5 RES, MF, 1/6m, 13,100 MED, MF, 1/6m, 13,100 MED, MF, 1/6m, 13,100 MED, MF, 1/6m, 13,121 MED, MF, 1/6m, 13,124 MED, MF, 1/6m, 13,124 MED, MF, 1/6m, 13,124 MED, MF, 1/6m, 13,125 MED, MF, 1/6m, 13,125 MED, MF, 1/6m, 13,125 MED, MF, 1/6m, 13,125 MED, MF, 1/6m, 13,100 MED, MF, 1/6m, 12,100 MED, MF, 1/6m, 12,1	NH550-8281F NH550-8287F NH550-9000F NH550-9000F NH550-1000F NH600-1240F NH600-1240F NH600-1240F NH600-1240F NH600-1240F NH600-4033 NH600-4033 NH600-4033 ASSEMBLY M 1100-00-0	THM IPR IPR THM TRM TRM TRM TRM TRM TRM TRM TRM TRM TR	4701-03-8251 4701-03-8259 4701-03-9099 4701-13-1004 4701-13-1210 4701-13-1240 4701-13-4983 4701-13-4883 4701-13-4999	3 1 2 1 1 1 2 1 2 4 1 1	015 GL6 037 G49 039 G46 011 021 U22 027 U28 027 031 040 D6 010 011 014 017 U19 033 024 024 030 032 037 031 041 041 049 038 045 01 05 01 05 010 U20 02 03 07 08 00 NONE NONE NONE NONE SN1	TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB,WPP, 201503 TRAMB,041, 201601000000000000000000000000000000000	2H3640 2H3606 2H3903 2h3905 2h5160 2H5606 182-561-55 182-501-55 182-501-53 167-600 211-33-001 215-33-001-01-22 ARREMANLY 1107-00	FAIR HOT FAIR HOT NSC NVTK NVTK C18 C18 C18	4901-03-0400 4901-03-0500 4901-03-7050 4901-05-1000 4901-05-2840 4908-00-0004 4908-00-0004 5104-07-0005 5104-07-0005	17 2 2 2 1 1 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1	NONE 163 164 165 035 048 161 162 166 169 167 168 167 1	TILL THILL PERSONNELL REMOVE ALL BLANES AND STAAL BLANES AND STAAL BLANES AND STAAL BLANES	150-PHITE/GREEN MA-701 AD 812 AC1850* CA-3049 CA-3049 CA-31408 ASSEMBLE 1100-05 PAGE1 TOTTEGE ONLERWIS SECURIO ONLERWIS SECU	CAVIT 10000-52-2039 PAIR 17600-07-0160 MOD 17000-10-1000 MC 17000-10-1000 RCA 17000-50-0001 RCA 17000-51-0001 MC 17000-51-0001 CENERATOR
R236 R249 R58 R59 R122 R226 R271 R7 R233 R229 R222 R279 R01 R223 R240 R226 R225 R226 R227 R51	MED, MF, 1/6m, 12,6,25% RES, MF, 1/6m, 13,02,5 RES, MF, 1/6m, 13,100 MED, MF, 1/6m, 13,100 MED, MF, 1/6m, 13,100 MED, MF, 1/6m, 13,121 MED, MF, 1/6m, 13,124 MED, MF, 1/6m, 13,124 MED, MF, 1/6m, 13,124 MED, MF, 1/6m, 13,125 MED, MF, 1/6m, 13,125 MED, MF, 1/6m, 13,125 MED, MF, 1/6m, 13,125 MED, MF, 1/6m, 13,100 MED, MF, 1/6m, 12,100 MED, MF, 1/6m, 12,1	NH550-8281F NH550-8287F NH550-9000F NH550-9000F NH550-1000F NH600-1240F NH600-1240F NH600-1240F NH600-1240F NH600-1240F NH600-4033 NH600-4033 NH600-4033 ASSEMBLY M 1100-00-0	THM IPR IPR THM TRM TRM TRM TRM TRM TRM TRM TRM TRM TR	4701-03-8251 4701-03-8259 4701-03-9099 4701-13-1004 4701-13-1210 4701-13-1240 4701-13-4983 4701-13-4883 4701-13-4999	3 1 2 1 1 1 2 1 2 4 1 1	015 GL6 037 G49 039 G46 011 021 U22 027 U28 027 031 040 D6 010 011 014 017 U19 033 024 024 030 032 037 031 041 041 049 038 045 01 05 01 05 010 U20 02 03 07 08 00 NONE NONE NONE NONE SN1	TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB TRAMB,WPP, 201503 TRAMB,041, 201601000000000000000000000000000000000	2H3640 2H3606 2H3903 2h3905 2h5160 2H5606 182-561-55 182-501-55 182-501-53 167-600 211-33-001 215-33-001-01-22 ARREMANLY 1107-00	FAIR HOT FAIR HOT NSC NVTK NVTK C18 C18 C18	4901-03-0400 4901-03-0500 4901-03-7050 4901-05-1000 4901-05-2840 4908-00-0004 4908-00-0004 5104-07-0005 5104-07-0005	17 2 2 2 1 1 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1	NONE 163 164 165 035 048 161 162 166 169 167 168 167 1	TOTAL TOTAL PCA, CEMERATOR AMBOURTAL BURNE SAMP FOCE MATTERIAL	150-PHTE/GREEN MA-701 AD 912 MC1450- CA-3009 CA-3009 AREAMAN 1100-00 PAGE1 THISTORY THISTOR	CAVIT 10000-52-2098 ANDEN 7000-07-0100 ANDEN 7000-07-0100 MCA 17000-10-001 ACA 17000-53-0001

